



- de** Montageanleitung
- en** Mounting instructions
- fr** Instructions de montage
- sv** Monteringsinstruktion
- nl** Montage-aanwijzing
- it** Istruzioni di montaggio
- fi** Asennusohje
- es** Instrucciones de montaje
- da** Monteringsvejledning

QVE1900



DN	(mm)	Nr.		$Q_{max.} (m^3/h)$	$\leq 0,8$	$\leq 2,8$	$\geq 1,3$	$\geq 3,0$
32	29 x 34	1		3.6	$\leq 0,8$	$\leq 2,8$	$\geq 1,3$	$\geq 3,0$
40	29 x 34	1		4.8	$\leq 1,1$	$\leq 3,7$	$\geq 1,7$	$\geq 4,0$
50	29 x 60	1+2		7.3	$\leq 2,2$	$\leq 5,7$	$\geq 3,1$	$\geq 6,1$
65	29 x 60	1+2		8.4	$\leq 2,7$	$\leq 6,5$	$\geq 4,0$	$\geq 7,0$
80	29 x 89	1+2+3		13.7	$\leq 4,3$	$\leq 10,7$	$\geq 6,2$	$\geq 11,4$
100	29 x 92	1+2+3+4	4 / 92 mm	22.1	$\leq 6,1$	$\leq 17,3$	$\geq 8,0$	$\geq 18,4$
125	29 x 117	1+2+3+4	4 / 117 mm	32.2	$\leq 9,3$	$\leq 25,2$	$\geq 12,9$	$\geq 26,8$
150	29 x 143	1+2+3+4	4 / 143 mm	39.2	$\leq 12,3$	$\leq 30,6$	$\geq 16,8$	$\geq 32,7$
200	29 x 167	1+2+3+4		113	$\leq 38,6$	$\leq 90,8$	$\geq 46,1$	$\geq 94,2$



1592M03